


Anton Oliver.

CX3 -kaasugrilli/-gasgrill


Asennusohjeet
Monteringsinstruktioner




Lue käyttöohjeet!
Läs bruksanvisningen!

12		*1	19		*1	A	M6*12		*28
13		*1	20		*2	B	M6*65		*12
14		*1	21		*2	F	M5*50		*4
15		*1	22		*1	H	∅18*∅6.5		*4
16A		*1	23		*1	I	M10		*2
16B		*1	24		*1	J	M4*10		*2
17		*1				K	∅10.3*∅19		*4
18		*1							


1 J*2
B*4




3 A*4




2 A*4




4 A*4




5 I*2
K*4




7 B*4





6 A*4






8 B*4




9 A*3 




11 H*2 
A*2 





10





12 A*1 




13 A*3 





15 H*2
A*2 




14



16 A*1 




17




19

F*2




18


F*2




20



21




23



OK

22



1 x 9 V (LR61) -paristo.
Ostettava erikseen.